



Hardware Guide

WiFi



EG Declaration of Conformity

The following product

IRTrans WiFi

is confirmed to comply with

DIN EN 55024: 1998 + A1: 2001 + A2: 2003.



Contents

1. IRTrans WiFi / WLAN	4
1.1 Connections	4
1.2 Power supply	4
1.3 USB connection / installing drivers	5
1.4 Settings / startup	5
1.5 Web Interface	6
1.6 Jumpers.....	7
2. External IR Transmitters	10
3.1 stick on minitransmitters	10
3.2 external high power transmitters	10
3.3 Devices with 2X option	11
3. Connecting external IR receivers.....	11
4. RS232 interface	11

1. IRTrans WiFi

The IRTrans WiFi is an IR transceiver with WLAN (IEEE 802.11bgn) interface. Basic features include:

- Receive and transmit IR
- 1 output for external IR transmitters
- 1 input for external IR Empfängers
- WLAN (IEEE 802.11bgn)
- USB connection for configuration

1.1 Connections

On the back there are left to right:



IRTrans WiFi back

- USB connector (Mini USB)
- Connector for power supply
- 2nd output (not active without 2X option)
- WLAN Status LED
- 1st output

The left 3,5mm jack is present on all IRTrans devices but not active unless a second output (2X option) or bidirectional RS232 option is installed.

1.2 Power supply

The IRTrans Ethernet is powered by an external power supply. It must deliver 8-16V and 300mA per IRTrans device. The positive lead is wired to the center terminal of the 5,5/2,1mm hollow connector. Powering the IRTrans by USB is not possible.

1.3 USB connection / installing drivers

The IRTrans WiFi is equipped with a mini USB connector for configuration and firmware updates.



IPAssign does not work with IRTrans WiFi. Use USB for configuration.



Before connecting the IRTrans to the PC the software / drivers must be installed.

Windows 2000 / XP / Server 2003 / Vista / 7

IRTrans USB drivers are digitally signed and included in the IRTrans software installer (setup.exe). Furthermore the drivers are available from the Microsoft driver database as well.

After connecting the IRTrans driver installation will start automatically.

Linux / MAC

Drivers and the configuration software are located on the cd in the folder linux or mac respectively or can be downloaded from the IRTrans website. This software requires Java JRE 1.6 or later.

1.4 Settings / Start-Up

For the first start-up the IRTrans WiFi has to be configured by USB.

For this purpose use the configuration software „IRConfig. The WLAN settings are available through the tab „WLAN / IP“. Most important are „SSID“, „WLAN Preshared Key“ and DHCP or fixed IP as applicable.

After writing these settings to the device it will try to start the WLAN connection. Color codes for the WLAN status LED are:

- off: WLAN deactivated / not configured
- Solid red: no WLAN connection
- Solid green: WLAN connection
- Flashing green: transferring data
- Flashing red: error during connection

WLAN troubleshooting

In most cases the WLAN connection will work after entering SSID and Key. Here are a few tips in case there is a connection problem:

- Sometimes there are problems with access points that have a hybrid B/G mode. In this case select either B or G.
- Selecting a lower speed in the WLAN settings also helps sometimes.
- Using a fixed IP instead of DHCP sometimes solves problems as well.

If there is an error with the WLAN connection there will be an error code displayed in the configuration dialogue:

Error	1-3	Error initialising the radio module (Hardware problem)
Error	4	Error scanning available WLANs
Error	5	Error reading parameters of the radio module
Error	6/7	Error setting WLAN parameters (SSID/Channel)
Error	8	Error setting the WLAN Key
Error	9	Error connecting to the WLAN
Error	10	Error setting the IP Parameter
Error	11-14	Error opening the TCP / UDP sockets
Error	15	Error verifying the IP parameters
Error	16	connection aborted by USB access

1.5 Web Interface



First configuration has to be done by USB.

Once the IRTrans is accessible by network further configuration can be done using the integrated web interface. Additionally the IRTrans software may be used via network as well as USB.


IRTrans devices with Ethernet offer a browser based configuration interface. All parameters that can be altered by the web interface can be accessed by the IRTrans servers device status dialogue as well.

To access the web interface simply type the IP adress of the IRTrans in an internet browser:

<http://192.168.0.32>

The adress will change according to your network settings.

Now you will see the Login page:



To access the configuration enter username and password. The default password is::

username: admin

password: irtrans

This password may be changed by clicking „Change Password“

All options accessible through the webinterface are identical to the corresponding options of the device status. For a detailed description refer to the software handbook.

1.6 Jumpers

Inside the IRTrans WiFi there are several jumper for configuration purposes. These will be set by factory and must not be altered.



Changing jumper settings inside the IRTrans will not activate additional features. It may however result in the IRTrans not working correctly anymore.

The IP Settings dialog to configure the IP parameter. The following fields are defined:

Use DHCP: Activates the automatic IP assignment via DHCP.

Fallback ...: When no DHCP server is available the device falls back to the default address 192.168.0.32 after 30s.


IP Address: Manually configured IP address

Subnet mask: Manually configured IP subnet mask

Default Gateway: Manually configured default gateway


In the lower lines the currently active parameters including the MAC address are displayed.

The button „Store Configuration“ transfers all values to the non-volatile EEPROM of the device.



The Access Rights dialog configures the access rights of the device. If no values are entered here, any client can access the device. As soon as at least one value is entered only clients that fit into at least one of the entries are allowed to access the device.

Each entry consists of an IP address and a subnet mask: 192.168.0.0 / 255.255.255.0 enables all clients within the network 192.168.0.x. An entry 192.168.0.1 / 255.255.255.255 allows only one client to use the iRTrans LAN. The access rights are active for all TCP and UDP functions.




To avoid a complete lock-out it is always possible to access the web front end from within the local network of the device – even if there is no entry for that subnet.

The IR Relay configuration is used to configure the relaying of IR signals from one IRTrans Ethernet to another. In general IR signals received by other IRTrans Ethernet modules will be relayed automatically. This relaying works without a server – even with IRTrans devices without an integrated IR database. The exact configuration of the relaying is done in this dialog.

In the list below “Accept IR Relay from” all IRTrans IP Addresses can be entered from which IR relaying should be enabled. If the list is empty, all signals will be relayed.

The list below “Send IR Relay to” tells the system to which devices received IR codes should be relayed. Normally it is enough to enable the checkbox „Broadcast IR Relay“. Only if IR data should be relayed to routed networks it is important to enter a target address because broadcasts will not be routed. The IR receiving of the irserver is also done via that broadcasts. That means either broadcast has to be enabled or the address of the host running the irserver has to be in this list – otherwise the irserver will not receive IR codes from this IRTrans module.


The UDP Broadcast fields are only used for modules with integrated IR Database. They define to which address and port formatted IR receive data has to be sent. The precise format of these telegrams is configured via the IR database.



The IR parameters can either be configured using the IRTrans GUI client or via the webpage “IR Configuration”.

All the fields and their meanings are explained in detail in the Users manual for the IRTrans system.

Of course both ways of configuration can be used alternately.



2. External IR transmitters

There are a variety of external transmitters available with 3,5mm jacks.

2.1 stick on minitransmitters

The minitransmitters can be stucked directly to the IR receiver of the your devices. Please note:

- The transmitter casing is not transparent all the way around. The transmitters will only work when the paper of the sticker is removed.
- Range is limited to 20-30cm (~1ft). The transmitters should be stucked directly to the IR receiver.
- Individual control of multiple external transmitters is not possible with the IRTrans devices covered by this handbook.
- Standard cable length is 1,8m (~6ft). Cables may be extendet to up to 5m (~15ft). Longer cables may cause signal distortions.
- Important: When using external high power transmitters there is a jumper to enable full power. This jumper must be removed when using minitransmitters.


2.2 external high power transmitters

The external high power transmitters are equal to the built in IR LEDs. They are available in a high frequency version as well (455kHz). The high frequency transmitters can be recognised by clear LEDs. High power transmitters can be connected to all of the IRTrans devices.

Cables should not be extended beyond standard length (1,8m~6ft). Longer cables lead to distorted IR signals.

For using external high power transmitters a jumper has to be set inside the IR-Trans. The following pictures illustrate the position of this jumper:

The jumper must not be set when using stick on minitransmitters!



2.3 Devices with 2X option

IRTrans modules with 2X option offer a second independent output for external transmitters. This is normally done by the 2nd (left) 3,5mm jack. If the IRTrans is equipped with a RS232 interface the RS232 interface will use the left jack and the 2nd IR output is available by stereo plug on the first (right) jack. Note: When ordering external transmitters this must be taken into account.

3. Connecting external IR receivers

External receivers can be connected by a 3,5mm jack next to the built in IR receiver.

When using an external receiver it must be enabled in the device settings and the correct receiver type has to be selected.



When using external receivers firstly the receiver must be enabled and secondly the correct receiver type has to be selected with the IRTrans software.

4. RS 232 interface

The IRTrans WiFi is available with a bi directional RS232 interface. The active RS232 cable must be connected to the 2nd (left) output on the IRTrans.



If the IRTrans is equipped with the optional RS232 interface the 2nd IR output (2X option) will be available by stereo plug using the right 3,5mm jack.

